Popouts Assignments in PIP/LSPx

1   Navigate to https://fcepip.intel.com/popout or https://lspx.intel.com/popout

2   Navigate to the "Popout" tab

Manually assign Popouts and POCs to a tool

3 Click the "Enter Tool" field.

4 "Start typing in the tool to which you want to assign Popouts and select from the list. For example, "NST145-1 (706N)"

5 Click the "Search Popout..." field to filter the list of Popouts in the the facility. For example, type Type "Q/4/" to see a list

| | | Search by Grid Number | | Search Popout... | | View Report | Clear Filte |

⋮ Status   ⋮ Roxtec   ⋮ Current Assignment   ⋮ Future Assignr

⚠

No Popout to display!

6 See the returned list of Popouts, with additional information:

- Status [Air, Open, Used Dry, Not Usable, Closed]
- Roxtec
- Current assignments
- Future assignments
- Install date
- Notes

7 Select the POCs that will be associated with the Popout. For example, click "D101", "D104", "D152", "D154"

If you want to unselect a POC, simply click it again. Click "×" in the POC list to clear all the selected items.

8 Once all POCs are selected, click on the "Assign POC" button.

⚠️ **What happens when the selected POC is already assigned to a Popout?**

9 If the POCs are already assigned to a Popout, you can choose:

- "Reassign" to move the selected POCs to the Popout.

- "Add Assignment" to add the POCs to new Popouts whilst maintaining the assignment on the existing Popouts.

10 Clear the "Search Popout..." field to see all the Popouts assigned to the selected tool.

Mark a Popout that is used for Heating Ventilation and Air Condition (HVAC)

⚠ Mark a Popout that is used for Heating Ventilation and Air Condition (HVAC)

11 Click on the "Airgrate" icon to mark a Popout for HVAC. This can only be done for Popouts that are not assigned.

Popouts that have Airgrate cannot be assigned to the tool.

12 Confirm that an Airgrate will be installed for this Popout.

13 Once a Popout has been assigned an Airgrate, the status will change to "Air". Click the "more" icon to delete an Airgrate from a Popout.

|	Popout ↑	Status	Roxtec	Current Assignment	Future Assignment	Notes	
🪰	BA/10/A10	Used Dry		⋮	STO726-1 D991 Install : 18 Sep 2025		⋮
🪰	BA/10/A6	Air		⋮			⋮
🪰	BA/10/A7	Used Dry		⋮	STO726-1 D991 Install : 18 Sep 2025		⋮
🪰	BA/10/A8	Open		⋮			⋮
🪰	BA/10/A9	Open		⋮			⋮
🪰	BA/10/B10	Open		⋮			⋮
🪰	BA/10/B6	Open		⋮			⋮
🪰	BA/10/B7	Open		⋮			⋮
🪰	BA/10/B8	Open		⋮			⋮
🪰	BA/10/B9	Open		⋮			⋮
🪰	BA/10/C10	Open		⋮			⋮
🪰	BA/10/C6	Open		⋮			⋮
🪰	BA/10/C7	Open		⋮			⋮
🪰	BA/10/C8	Open		⋮			⋮
🪰	BA/10/C9	Open		⋮			⋮
🪰	BA/10/D10	Open		⋮			⋮
🪰	BA/10/D6	Open		⋮			⋮

Search by Grid Letter   Search by Grid Number   ba/   View Report   Clear Filter   Export to excel   + Add Tool   + Add Popout   🗑 Delete assignments

eports   RP Schedule   Ireland ▼   Hi, Simeon Onaola ⚙ ℹ 🐞 🔔 3

---

14 Click "Delete Airgrate"

Status	Roxtec	Current Assignment	Future Assignment	Notes	
Used Dry		⋮	STO726-1 D991 Install : 18 Sep 2025		⋮
Air		⋮			⋮
Used Dry		⋮	STO726-1 D991 Install : 18 Sep 2025	☰ Detail	
Open		⋮		❓ Clear Popout	
Open		⋮		⊖ Obstructed	
Open		⋮		💧 Spilldam	
Open		⋮		💬 Comment	
Open		⋮		✏ Update	
Open		⋮		🗑 **Delete Airgrate**	
Open		⋮			⋮
Open		⋮			⋮
Open		⋮			⋮
Open		⋮			⋮
Open		⋮			⋮
Open		⋮			⋮
Open		⋮			⋮
Open		⋮			⋮
Open		⋮			⋮

15 Confirm that you want to delete the Airgrate by clicking "Yes"

Updating Popout assignments on a tool

⚠️ Deleting existing Popout assignments from a tool

16   To remove existing Popout assignments on a tool, click "Delete assignments"

	View Report	Clear Filter	Export to excel	+ Add Tool	+ Add Popout	🗑 Delete assignments

Current Assignment ⋮	Future Assignment ⋮	Notes ⋮	
NST144-1 E20,E17,E18,E19,E09 ⋮	NST144-1 E20,E17,E18,E19,E09	Install : 08 May 2017	⋮
NST144-1 E01,E02,E04,E05,TC1-P1-WS,TC1-P2-TL ⋮ 1,E24,E13,E12,E06,E07,E08,E11,E10	NST144-1 E01,E02,E04,E05,TC1-P1-WS,TC1-P2-TL Install : 08 May 2017 1,E24,E13,E12,E06,E07,E08,E11,E10		⋮
NST144-1 G551,P368,P360,P364,G552,G553,X40 ⋮ 4,W721	NST144-1 G551,P368,P360,P364,G552,G553,X40 Install : 08 May 2017 4,W721		⋮
NST144-1 P508,P506,P369,P361,X512,D503,P36 ⋮ 5,X513,D403	NST144-1 P508,P506,P369,P361,X512,D503,P36 Install : 08 May 2017 5,X513,D403		⋮
NST144-1 P504,P502,P375,P373,X511,X510,P374, ⋮	NST144-1 P504,P502,P375,P373,X511,X510,P374, Install : 08 May 2017		⋮

17   A popup will appear, asking you to confirm the removal of existing Popout assignments. Click "Yes" to confirm.

Confirm Deletion of Popout Assignments

You are about to delete Popout assignments for **NST145-1 (706N)**. Please note that not all Popout assignments will be deleted immediately. The following conditions apply:

- Popouts with the assignment type "Airgrate".
- Popouts where the active date of the tool is after today's date.
- Popouts that have valid previous airgrate assigned to them.

To ensure complete deletion of all applicable Popout assignments, you may need to click the "Delete Assignments" button again.

Are you sure you want to proceed with the deletion? Please confirm by clicking "Yes" or choose "Cancel" to abort the operation.

Yes   Cancel

ℹ️ Add a new Popout to the database

18 If the Popout does not exist in the database, click "Add Popout"

19 When the popup appears, enter all the necessary details about the new Popout. Then click "Add"

ⓘ Add a new Tool to the database

20 If the Tool you are looking for does not exist in the database, click "Add Tool"

21 Select "Tool" and add all complete the mandatory fields.

If you don't specify the life of a tool, it will be considered as a "Load".

View all Popouts in a Facility

22 Click the "Facility" dropdown.

23   Select a facility.

24   See the list of all Popouts and their assigned tools and POCs within the Facility.

Filtering the list

25 Click the three dots on the column that you want to filter.

Type a few characters, set the parameters and click "Filter"

26 Click "Clear Filter"